



## **New functions in firmware**

**Version 3.1 – June 2011** 

- Improved performance of the constellation diagrams
- Improvement of the SAT-CR auto scan detection mode
- Possibility to enter the SAT-CR userbank frequencies with the keyboard
- An acoustic beep tone in relation to the signal level can be switched on or off.

  This function is only available in the level measurement menu (Standard setting = beep tone off)